Quick Reference to Keys

A

Key	Function		
● ●	Moves the cursor left and right so you can scroll the entry line. Press 2nd ① or 2nd ① to scroll to the beginning or end of the entry line.		
\odot	Moves the cursor up and down so you can see previous entries. Press 2nd ⊙ or 2nd ⊙ to scroll to the beginning or end of the history.		
+-×÷	Adds, subtracts, multiplies, and divides.		
0-9	Enters the digits 0 through 9.		
	Opens a parenthetical expression.		
	Closes a parenthetical expression.		
X ⁻¹	Calculates the reciprocal.		
<i>x</i> ²	Squares the value.		
π	Enters the value of pi rounded to 10 digits (3.141592654).		
•	Enters a decimal point.		
(-)	Indicates the value is negative.		
\land	Raises a value to a specified power.		
0 / 11	Displays the following menu that lets you specify the unit of an angle.		
	Specifies degrees.		
	r Specifies radians.		
	g Specifies gradients.		
	DMS Specifies degrees (°), minutes (′), and seconds (″). It also lets you convert an angle from decimal degrees to DMS notation.		
2nd	Turns on the 2nd indicator and accesses the function shown above the next key that you press.		
2nd [10 ^x]	Calculates the common antilogarithm (10 raised to the power of the value).		
2nd [√]	Calculates the square root.		
2nd [%]	Changes a real number to percent. Results display according to the Decimal Notation mode setting.		
2nd [,]	Enters a comma.		
[2nd [¾-]	Calculates the specified root (x) of the value.		

	١
	١
•	1

Key	Function		
Ab/c	Lets you enter mixed numbers and fractions.		
[2nd] [Ab/c◆d/e]	Converts a simple fraction to a mixed number or a mixed number to a simple fraction.		
2nd [ANS]	Recalls the most recently calculated result, displaying it as Ans .		
CLEAR	Clears characters and error messages on the entry line. Once the display is clear, it moves the cursor to the last entry in history.		
2nd [CLRVAR]	Clears all memory variables.		
COS	Calculates the cosine.		
2nd [COS-1]	Calculates the inverse cosine.		
DATA	Lets you enter the statistical data points (x for 1-VAR stats; x and y for 2-VAR stats).		
DEL	Deletes the character at the cursor. If you hold <code>DEL</code> down, it deletes all characters to the right. Then each time you press <code>DEL</code> , it deletes 1 character to the left of the cursor.		
DRG	Displays the following menu that lets you change the Angle mode to degrees (°), radians (r), or gradients (g), and then back to degrees without affecting the value in the display. DEG Sets degree mode.		
	RAD Sets radian mode. GRD Sets gradient mode.		
	When you turn on the TI30X IIS, it is always in the DEG mode.		
[2nd] [e ^x]	Calculates the natural antilogarithm (e raised to the power of the value).		
2nd [EE]	Lets you enter and calculate the exponent.		
EN <u>T</u> ER	Completes the operation or executes the command.		
[2nd] [EXIT STAT]	Displays the following menu that lets you clear data values and exit STAT mode. EXIT ST: Y N		
	Press ENTER when Y (yes) is underlined to clear data values and exit STAT mode.		
	Press $ \frac{\text{ENTER}}{\text{ENTER}} $ when N (no) is underlined to return to the previous screen without exiting STAT mode.		



		<u> </u>			
Key	Function	Function			
[2nd] [F ◆ D]		Converts a fraction to its decimal equivalent or converts a decimal to its fractional equivalent, if possible.			
2nd [FIX]	Displays the f	Displays the following menu that lets you set the number of decimal places.			
	F0123	456789			
	F	Sets floating decimal (standard) notation.			
	0-9	Sets number of decimal places.			
(2nd) [HYP]		Accesses the hyperbolic (sinh, cosh, tanh) function of the next trig key that you press.			
2nd [INS]	Lets you inse	Lets you insert a character at the cursor.			
[2nd] [K]	Turns on the	Turns on the constant mode and lets you define a constant.			
LN	Calculates th	Calculates the natural logarithm (base e , where $e=2.718281828459$).			
LOG	Calculates th	Calculates the common logarithm (base 10).			
MEMVAR	Displays the following menu of variables.				
	ABCDE				
2nd [OFF]	Turns off the	Turns off the calculator and clears the display.			
ON	Turns on the	Turns on the calculator.			
PRB	Displays the f	following menu of functions.			
	nPr	Calculates the number of possible permutations.			
	nCr	Calculates the number of possible combinations.			
	!	Calculates the factorial.			
	RAND	Generates a random 10-digit real number between 0 and 1.			
	RANDI	Generates a random integer between 2 numbers that you specify. Separate the 2 numbers with a comma.			
[2nd] [RCL]	Recalls the st	Recalls the stored values to the display.			

© 1999 TEXAS INSTRUMENTS INCORPORATED

TI-30X IIS: A Guide For Teachers

A-3

	1	١	ı
1	7		١

		<u>.</u>		
Key	Function			
2nd [RESET]	Displays the R	ESET menu.		
	RESET:	<u>N</u> Y		
		when $oldsymbol{N}$ (no) is underlined to return to the previous screen setting the calculator.		
		when Y (yes) is underlined to reset the calculator. The IEM CLEARED is displayed.		
	· ·	ON and CLEAR simultaneously to reset the calculator y. No menu or message is displayed.		
2nd [R⇔P]	Displays the fo	ollowing menu that lets you convert rectangular coordinates		
	(χ,y) to polar of	coordinates $(r, heta)$ or vice versa.		
	R▶Pr	Converts rectangular coordinate to polar coordinate r .		
	R▶Pθ	Converts rectangular coordinate to polar coordinate $ heta$.		
	P▶RX	Converts polar coordinate to rectangular coordinate $\pmb{\chi}$.		
	P▶Ry	Converts polar coordinate to rectangular coordinate y		
2nd [SCI/ENG]	Displays the fo	Displays the following numeric notation mode menu.		
	FLO	Restores standard mode (floating decimal).		
	SCI	Turns on scientific mode and displays results as a		
		number from 1 to 10 (1 \leq n $<$ 10) times 10 to an integer		
	ENG	power.		
	ENG	Turns on engineering mode and displays results as a number from 1 to 1000 (1 ≤ n < 1000) times 10 to an		
		integer power. The integer power is always a multiple of		
		3.		
SIN	Calculates the	Calculates the sine.		
2nd [SIN-1]	Calculates the	Calculates the inverse sine.		
2nd [STAT]	Displays the fo	ollowing menu from which you can select 1-VAR, 2-VAR, or		
	1-VAR	Analyzes data from 1 set of data with 1 measured variable—x.		
	2-VAR	Analyzes paired data from 2 sets of data with 2 measured variables—x, the independent variable, and y, the dependent variable.		
	CLRDATA	Clears data values without exiting STAT mode.		



Key	Function		
STATVAR	Displays the fol	lowing menu of stat variables with their current values.	
	n	Number of x (or x,y) data points.	
	\overline{x} or \overline{y}	Mean of all x or y values.	
	Sx or Sy	Sample standard deviation of x or y.	
	σx or σy	Population standard deviation of x or y.	
	Σx or Σy	Sum of all x values or y values.	
	Σ x2 or Σ y2	Sum of all x 2 values or y 2 values.	
	Σχγ	Sum of $(x \times y)$ for all xy pairs in 2 lists.	
	а	Linear regression slope.	
	Ь	Linear regression y-intercept.	
	r	Correlation coefficient.	
ST0▶	Displays the fol	lowing menu of variables.	
	ABCDE	Lets you select a variable in which to store the displayed value. The new variable replaces any previously stored value.	
	rand	Lets you set a seed value for random integers.	
TAN	Calculates the	Calculates the tangent.	
2nd [TAN-1]	Calculates the inverse tangent.		